


User Manual for SmartWi

This user manual will introduce you to the SmartWi Step-by Step and provide quick reference for its operation. Please read it completely and keep it for future reference.

We welcome your comments and suggestion regarding the SmartWi on the website

www.SmartWi.net

The **SmartWi** Master unit need from the power adaptor or from a USB port on the Pc.




1. Connect the power adaptor to the **SmartWi** master, the turn on the power.
2. The green LED will light.

3. Marriage your client card to the **SmartWi** master box.
Inset 1 client card in the **SmartWi** master box and wait 5 – 10 sec.
Repeat step 3 for the other client card.
4. Now inset your smartcard for your Satellite, Cable or Terrestrial receiver, into the **SmartWi** master unit with CHIP as shown on top of master box



5. Inset one of the **SmartWi** Client Card in the Satellite, Cable or Terrestrial DVB receiver.



The Satellite, Cable or Terrestrial DVB receiver will see the **SmartWi** wireless Card as the original smartcard. You can address up to 7 client card and watch minimum 4 different channels at the same time.

Note.

Some receivers need the ATR-String transferred to the client card for fast answering the receiver.

How to transfer ATR to Client card.

1. Connect the power adaptor to the **SmartWi** master.
2. Place the original smartcard in to the **SmartWi** Master as shown on top of the Master box & wait 5 sec.
3. Remove the smartcard from the **SmartWi** master.
4. Now inset Client card in the Master box and wait until green LED start flickering. The ATR are now transferred to the client card.
5. Now place the original card in the master box and the client card in the receiver witch need a fast reply from the card.